Landroid®M WIFI Connection Guide







1. Connect Landroid®M with the wireless router

- 1.1. Select "Setup WIFI" to scan for WIFI network around you, then select your WIFI network by using the ↑ ↓ keys.
- 1.2. Enter the password if necessary:

Press **OK** to enter the password interface.

Using the keyboard on machine to input password characters (as shown in Fig. 5):

Press 2-4-6-8 to select the character,


Press 5 to confirm the character,

Press 1 to delete the character.

Press **OK** to confirm the password.

1.3. Select module state by using the \(\subseteq \subseteq \keys \), then select "connect" and it will remind you by "connected!" after connected successfully.


Note: When "Disconnected "occurs, pls confirm your WIFI password or move your Landroid®M closer to the router. If still not connected, check if the DHCP is set to "Yes" (see "Ipv4 setting"), or restart the router.



Disconnected 000.000.000.000

SSID: PSW:

Module state:



connect

disconnect

Yes

1.4. Ipv4 Setting

Select "Ipv4 Setting" by using the ↑ ↓ keys and set the DHCP to "Yes".













2. Connect smart phone to your Landroid®M

- 2.1. To download the Landroid®M APP, use your mobile phone to scan the QR code below or download it from Playstore(google-android), AppleStore(Apple-ios).
- 2.2. Open the app. Sign up for an account. The registration step only requires an email. The service will send a response email to the given address with the Password.
- 2.3. Press scan, the smart phone will search your Landroid®M
- 2.4. Click directly on the name of your Landroid®M and then insert PIN (Default PIN: 0000).

Note: For first time use, please set your Landroid®M and smart phone under the same

Trouble shooting

Symptom	Cause	Action
Your Landroid®M has no reactions when operating from smartphone	The Distance between Your Landroid®M and the WIFI router is too far.	Try to reduce the distance between the router and your Landroid®M or Install a WIFI extender.
	Router isn't connected.	Check the Router connection. Restart the Router.
	No WIFI has been configured on your Landroid®M	Configure your Landroid [®] M in order to connect to your WIFI App.